





88!; HL &,) !J & `6 `cW_ `=bghU``Uh]c b


Danger Den LLC assumes no liability whatsoever, expressed or implied, for the use or installation of this product. These installation instructions are subject to change without notice.



Tighten screws until O-Ring diameter is equal to or slightly greater than the diameter of the washer.

Caution:
Do Not overtighten screws. Installing the screws too tight may cause video card to bend.
If video card show signs of bending, loosen screws slightly and recheck videocard for bending.

 = Apply Thermal Paste to indicated locations
 = Apply Thermal Pad to indicated locations



Items included in kit:

Discription	QTY
2-56 Screw	12
#2 SS Washer	12
#2 O-Ring	12
Thermal Grease	2 tubes
Thermal Pad	1 (3"x3")
Waterblock	1