



Normal Operation:

Input Connection: Pump needs to be fed from a T-Line or Reservoir for optimal operation

Output Connection: Normally connected to the CPU block for optimal performance but can also connect to other blocks or radiators.